

battat®

Childhood Is Magical!®

TWIST & SPIN™

110 lbs./50 kg
MAX WEIGHT

18
m+




Scan QR code for
video instructions

HOW TO PLAY


Push the top to see the balls pop!
Sit on the base and use the top to start spinning.




PIECES



1 Top




1 Pillar



1 Base


INSTRUCTIONS: Assemble on the floor
or on another non-scratch surface.

1 Line up the ribs and grooves.



2

Align the pillar with a table edge
as in Fig. 1, then press firmly on
the top piece using both hands
until you hear it click. Make sure
all the ribs are secured before
moving forward.




Final



DIMENSIONS


19 in (48.3cm) x 19 in (48.3cm) x 10.4 in (26.4cm)

3 Line up the ribs and grooves.



4

Press firmly until
you hear a click.



USER GUIDE

Keep this toy dry and store it inside after playtime.
Please remove all packaging materials before giving to children.
Please retain this information for future reference.

© 2024 MAISON BATTAT INC.
Manufactured for Maison Battat Inc.
8440 Darnley Road, Montreal, P.Q. H4T 1M4
Designed by Maison Battat Inc. Battat® is a registered
trademark of Maison Battat Inc.
Made In China.
All Battat® products meet all US standards.
Colors may vary.
Please retain this information for future reference.
Please remove all packaging materials before giving to children.



WARNING: Adult assembly required.

BT1810