



SWEET TREATS POP-UP SHOP™





PIECES













2 cupcake bottoms

2 cookies 2 ice cream scoops 2 ice cream cones 2 macarons 2 cupcake tops

6 cake pieces








1 cake server

2 spoons

2 plates


1 cake plate


(C) 1 dessert tray






HOW TO SET UP THE TRAY:








© 2024 MAISON BATTAT INC.


Manufactured for Maison Battat Inc. 8440 Darnley Road, Montreal, P.Q. H4T 1M4 Designed by Maison Battat Inc. Battat® is a registered trademark of Maison Battat Inc. Made in China. All Battat® products meet all US safety standards. Colors may vary. Please retain this information for future reference. Please remove all packaging materials before giving to children.

HOW TO FOLD AND STORE THE TENT:



HOW TO CORRECT THE TENT'S SHAPE:

If the tent's wire frame is bent, lift the top of the tent, bring both sides together, and then release to correct the shape. Repeat these steps if needed.



USER GUIDE

- The tent is not suitable for wet or rainy environments. If the tent gets wet, leave it open in an airy space to dry. To maintain quality, do not leave the tent in the sun for prolonged periods. Surface clean only.
- Young children require adult supervision when playing in the tent.

ATTENTION: For pretend play use only. Clean toy thoroughly before use.



MARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.

This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.